

How To Address an IC Controller

(2) - Address Settings

1  on
 2 
 3 
 4 
 5 
 6  
 7 
 8 
DS1

Locate the DS1 switch at the bottom-middle of the panel. For most proximity and biometric readers, ensure that switch 6 is set to ON (right). All others should be OFF (left).

Switch 1 2 3 4 5	Address	Switch 1 2 3 4 5	Address
0 0 0 0 0	00	0 0 0 0 1	16
1 0 0 0 0	01	1 0 0 0 1	17
0 1 0 0 0	02	0 1 0 0 1	18
1 1 0 0 0	03	1 1 0 0 1	19
0 0 1 0 0	04	0 0 1 0 1	20
1 0 1 0 0	05	1 0 1 0 1	21
0 1 1 0 0	06	0 1 1 0 1	22
1 1 1 0 0	07	1 1 1 0 1	23
0 0 0 1 0	08	0 0 0 1 1	24
1 0 0 1 0	09	1 0 0 1 1	25
0 1 0 1 0	10	0 1 0 1 1	26
1 1 0 1 0	11	1 1 0 1 1	27
0 0 1 1 0	12	0 0 1 1 1	28
1 0 1 1 0	13	1 0 1 1 1	29
0 1 1 1 0	14	0 1 1 1 1	30
1 1 1 1 0	15	1 1 1 1 1	31