Activating Doors from an Input -

To lock or unlock door from an input.

1. First Enable the input



2. Go to the system Functions tab



Activating Doors from an Input -

3. Click on the system functions tab and open the device information management.



4. Click on the the tab "output group to operate on input signal"

Assign a group code and give it your own group name. search and select the input device (the input you enabled).

In the two boxes below move the desired outputs from the left to the right column using the arrow buttons. Click on the operation mode and choose your desired action.

I have chosen unlock - Resume operation as this puts the outputs back into their normal operational mode